

SMARTFLOW® IceCube[™] Flowmeter

1/4" thru 3/4"NPT and BSPP

Installation and Operating Instructions

General

The Smartflow small flowmeter provides visual indication of flow through a clear polysulfone viewing body. The vane indicator is physically pushed by the liquid indicating the flow rate printed on the viewing body. Available options:

- Flow Rate in gallons per minute (gpm) or liters per minute (lpm)
- Temperature Gauge (Dual Scale)
- Pressure Gauge (Dual Scale 30 psi, 60 psi, 100 psi unfilled, or 100 psi liquid-filled)
- Quick disconnect fittings (NPT threads 1/2" or less)

Specifications

Flow Ranges (max.)	1.5 gpm, 2.5 gpm, 8.0 gpm
	10 lpm, 20 lpm, 30 lpm
Connection sizes (NPT or BSPP)	
Quick disconnect fittings (NPT only)	1/4", 3/8 or 1/2"
Operating Temperature (max.)	210°F (99°C)
Operating Pressure (max.)	100 psi (6.9 bar)
Accuracy	±10% of full scale

Component Materials

Viewing Body	Polysulfone
End Caps	
Sensing Vale	
Hinge Pin	SS
Torsion Spring	SS
Corner Screws	
O-Rings	EPDM

Replacement Parts

Hinge Pin	FP-10	
O-Ring	.568-214-5601-70	
Vane	FV-10	
Temp Gauge	FMT-1	
Pressure Gauges		
0-30 psi	FPG-30	
0.60 mai	EDG (0	
0-00 psi	FPG-60	
	FPG-60 FPG-100	
	FPG-100	

Springs

FSP-15
FSP-25
FSP-200
FSP-80
F-15
F-25
F-80
F-100
F-200
F-300



Cleaning

Debris in the circulating system may cause the sensing vane to stick or discolor the inside of the clear plastic body. Contact Burger & brown Engineering for replacement parts or repair service. Clean the flow meter as follows:

- 1. Remove the screw in each corner.
- 2. Remove the two end caps.
- 3. Remove the sensing vane from the body by pushing gently against the back of the vane.
- 4. Clean the body with a soft cloth or paper towel. Novus #2 plastic polish may be used. *Do not clean with acetone. Do not clean with abrasives such as scouring powder, sandpaper or emery cloth which will scratch the clear finish.*
- 5. Remove the torsion spring and hinge pin. Wipe clean with a soft cloth or paper towel. *Do not lubricate the spring or hinge pin.*
- Examine the o-rings and replace if they are hard, brittle or flattened. Add a thin layer of Parker Super-O-Lube or equivalent to the o-rings before replacing them. Do not use petroleum-based lubricants on EPDM o-rings.
- 7. Re-assemble parts in reverse order of disassembly. Do not over-tighten the screws as this may crack the viewing body.



4500 E 142nd Street Grandview, MO 64030, USA Tel. (816) 878-6675 • www.smartflow-usa.com





Caution

- Use at temperatures above 130°F poses a serious personal injury hazard. Use extreme caution, protective clothing, or shielding around the system to minimize risk to personnel and nearby equipment.
- Accelerated chemical attack will result if flowmeters are used at elevated pressures and temperatures.
 Frequently inspect the body for cracking or crazing which may indicate chemical attack. Sudden failure and leakage can result from chemical attack. Consult the chemical compatibility list at right for substances that attack the polysulfone flowmeter body.
- Any liquid system offers the potential for accidental leakage. Leakage onto electrical or computer equipment could result in costly damage or personal injury. Do not locate piping systems where leakage might damage equipment or pose personal injury hazards. If it is impossible to avoid piping in such locations, use shielding to protect equipment and personnel.

Chemical Compatibility

The following is a list of chemicals that are not compatible with the UDEL Polysulfone used in the Smartflow small flowmeter. Contact Burger & Brown Engineering for more detailed information.

Acetone, Methyl Ethyl Ketone Freon TA

Benzene Methylene Chloride Carbon Tetrachloride Tetrachloroethylene

Chlorobenzene 1,1,2,2-Tetrachloroethane Toluene

Chloroform 1,1,1-Trichloroethane Cyclohexanone Trichloroethylene

Esters Xylene

Please contact us for further information.

Burger & Brown Engineering, Inc.

4500 E 142nd Street

Grandview, Missouri, USA 64030

Toll Free: 1-800-764-3518 Tel: 816-878-6675

Fax: 816-868-6683 www.smartflow-usa.com

Limited Warranty

Seller warrants that Smartflow® products supplied will conform to the description stated in published literature, and that the product will be of standard quality. The seller warrants manufactured components for 90 days and electronic components within the Tracer® line for one year. This is the sole warranty made by Seller with respect to this product. Seller expressly disclaims any other express or implied warranties, including, but not limited to, the implied warranty of merchantability and the implied warranty of fitness for a particular purpose.

Seller shall not be liable for any cost or damages, whether direct, incidental or consequential, including, but not limited to, any injury, loss or damage resulting from the use of this product, regardless of whether any claim for such cost or damages is based on warranty, contract, negligence, tort or strict liability. The sole liability of Seller is limited to repairing or replacing this product.

This warranty shall not apply to any products that have been repaired or altered by anyone other than Seller. The warranty shall not apply to any products subject to misuse due to common negligence or accident, nor to any products manufactured by Seller which are not installed or operated in accordance with the printed instructions of Seller or which have been operated beyond the rated capacity of the goods. Seller states that the product's useful safe life is 5 years. Actual life may vary widely depending on operating environment such as temperature, pressure, and chemical exposure.

Burger & Brown Engineering, Inc. 816-878-6675